

[X-Clear Driveshaft Tunnel Brace](#)**034 MOTORSPORT**

This brace is designed to substantially increase rigidity over the factory unit, while adding an additional 15mm of clearance for aftermarket exhaust components.

**Installation Spiciness Rating: MILD**

Installation of your 034Motorsport X-Clear Brace is a straightforward process that will take approximately 30 minutes to complete.

**Supplied Parts:**

- 034 driveshaft tunnel brace
- (4x) M10x25mm bolts

**Tools Needed:**

- 16mm socket
- 8mm Allen bit
- Torque wrench

[About This Guide](#)

This Install Guide documents the installation process on a B8.5 Audi S4. There may be minor differences depending on specific vehicle, market, options, etc.

### Getting Started

Confirm you have received all the parts included with your purchase by reading the complete guide, if there are missing components, please contact:

[customerservice@034motorsport.com](mailto:customerservice@034motorsport.com)

**\*Exhaust pipes may be hot! Let them cool off before starting the installation.**

### Install Steps

#### Step 1

Lift the car to gain access to the underside.



#### Step 2

Using a 16mm socket, remove the factory hardware and set the brace aside.



#### Step 3

Using an 8mm Allen bit, secure the 034 X-Clear into the factory location.



#### Step 4

Torque the provided hardware to **45 Nm**.



#### Step 5

Stand back and appreciate all the rigidity and exhaust pipe clearance you now have.



#### Step 6

Lower the car back down and enjoy!

