



1. First we need to swap the curved cowl with the supplied flat cowl. make note of the position of this bracket with respect to the Eventuri Badge. Take a photo for easy reference. You will need to reinstall the bracket in the same position.



3. Now use the new flat cowl and re-install with the bracket. Make sure the bracket is in the same position with respect to the Eventuri badge.



2. Remove all screws and remove the bracket and curved cowl.



4. Install the new sealed duct in the same way as the original metal duct and secure with the 2 push rivets. Once secured – re-install the tube and filter housing assembly. You can follow the same guide as the original N55 installation guide found on our website in “downloads”.