

REAR SWAY BAR TECHNICAL INFORMATION



TECH SHEET NO.
TS025

VEHICLE MAKE
VOLKSWAGEN

PART NO.
71748-25

PLEASE READ BEFORE INSTALLATION

NOTE: Illustrations are for technical reference only and are approximate.
Mounting tabs, spring type, and other details may vary.

Kit includes:

1 x Sway Bar

2 x Bushing Band Clamp

2 x Bushings

2 x End Bushings

2 x Extended Shock Mount / Bar End Bolts

2 x Nuts

2 x Bushing Bracket

- H&R suspension components should only be installed by a qualified licensed mechanic experienced in the installation of suspension springs and shocks. The professional mechanic should have express knowledge of the special requirements of aftermarket suspension products.
- Follow all factory torque specifications and do not torque bolts until the vehicle has been lowered and the suspension loaded.
- For vehicles with ABS, rear ABS cable housing must be removed and the screws ground flush. see figures 1 & 2



fig. 1



fig. 2

- The bushing, bushing bracket and bushing band clamp must be installed on the sway bar and mounted to the axle as shown in figures 3 & 4. Note that the center-to-center measurement between bushings must be 22.8 inches (580mm).



fig. 3



fig. 4

- The ABS cable must then be attached to the rear axle beam with a cable strap. Please be careful to keep it away from any moving parts to ensure the cable is not damaged.
- The sway bar ends attach to the lower shock mounts with the supplied bolts (fig. 5 & 6).



fig. 5



fig. 6

NOTE: Final torque should be to OE recommended specifications and performed after the vehicle has been lowered to the ground.