

Note:  
Print template using Adobe Acrobat. Card stock and thick paper work best.  
Make sure to choose 'FULL SCALE' or '100%' option (NOT 'fit to paper').  
Before trimming, confirm dimensions with ruler to make sure template  
is printed with correct scale.

15 cm

4 inch

340mm Rotor

370mm Rotor

